

Thank you for purchasing one of our latest range of Homologated systems . This manual covers the following systems SPAeX2.0M. It is important that you read the following instructions carefully before attempting to install your fire suppression systems. The performance of these systems could be affected if they are in any way modified or tampered with and will void its homologation. Please ensure you only use genuine SPA parts should any part need replacing. Should you require assistance with this please call +44(0)1543 434580

Index	Pages
System contents	2
Engine bay/Cockpit nozzle locations	3-5
System layout	6
Lever valve assembly	7
Mechanical system fitting instruction	s 8
Tubing maintenance	9
Suppression data sheets	10

Manufacturers manual

### CONTENTS

SPAeX2.0M SYSTEM CONTENTS LIST 2 X SP147 5" MECHNICAL STRAPS 1 X SP 017 E LOCATION STICKER LARGE 1 X SP 0129 E LOCATION STICKER SMALL 4.5 X SP 015 6MM DECABON HOSE PER METER 2.5 X SP 032 8MM DECABON HOSE PER METER 1 X SP 072 10MM DECABON HOSE PER METER 0.5 X SP 181 12MM DECABON HOSE PER METER 1 X SP 184 8MM-6MM Y PIECE 1 X SP 183 10MM-8MM Y PIECE 1 X SP 182 12MM-10MM Y PIECE 1 X SP 182 12MM-10MM Y PIECE 1 X SP 186 10MM-8MM REDUCER 2 X SP 187 ENGINE BAY NOZZLES 2 X SP 188 COCKPIT NOZZLES

# COCKPIT NOZZLE LOCATION FOR SALOON CARS & SPORTS CARS

Two nozzles should be mounted in the cockpit area of a saloon car, we recommend that these are mounted under the dashboard spraying horizontally across the drivers foot-well and co-drivers compartment.

SALOON & SPORTS CAR NOZZLE POSITIONS



# ENGINE BAY NOZZLE LOCATION

Two nozzles should be mounted in Engine compartment fig 1



### TUBING

Each SPA Extreme system is supplied with Decabon tubing which is a coated aluminium tube which can be molded and flexed to suit this application. The SPA Extreme system has been designed using this type of tube. DO NOT substitute this tube for any other type.

### MULTI-DIRECTIONAL NOZZLES

Please note that nozzle shown in Fig.A must only be used in engine bay. Nozzle shown in Fig.B must only be used in cockpit.



It is important that the correct nozzles supplied with the system are used, the nozzles produce a multi directional spray pattern and must be positioned as shown in Fig A.

fig A





fig B

Yes

No

Engine Bay Nozzle	11
10mm-8mm Y-Piece	10
10mm Bulkhead Fitting	9
Cockpit Nozzle	8
6mm Decabon Hose (4.5 Meters)	7
8mm-6mm Y-Piece	6
8mm Decabon Hose (2.5 Meters)	5
10mm-8mm Reducer	4
10mm Decabon Hose (1 Meter)	ω
12mm-10mm Y-Piece	2
12mm Decabon Hose (0.5 Meter)	1
Part Description	

8



### LEVER VALVE ATTACHMENTS



Fig 3

#### MECHANICAL SYSTEM FITTING INSTRUCTIONS

This SPA Extreme system is mechanically operated, it uses two T handle pull cables one at 6 feet and one at 12 feet in length. Please read carefully the below instructions.

Unpack all parts and check against contents list page

Decide the best position for the extinguisher system - it is recommended that the bottle be mounted in the fore and aft direction of the vehicle.

It is important that the contents label and pressure gauge are clearly visible for scrutineering. Mount the bottle securely in the brackets.

Insert the tubing into the push-in fitting on the lever valve and lay the end of the tube from the cylinder to the chosen location for the nozzle, push the nozzle onto the tubing and orientate this to point the nozzle in the direction of the anticipated fire source.

### Make sure the safety pin is in place at all times during assembly.

# When installing cables it is important there are no kinks in the cable and no 'S' bends formed which may cause malfunction.

Mount the 6 foot cable in the cockpit within easy reach of the driver when sitting in the seat wearing the safety harnesses - the other end of the cable is to be threaded through one of the adjusting screws on the handle of the lever valve on the cylinder. **Fig 3** 

Once this is inserted through the clamp it is important to not have more than 6mm of play in the cable where it has been clamped.

Mount the 12 foot cable on the outside of the vehicle, (close to the exterior master switch is the recommended position).

Lay the cable in the vehicle and connect to the lever valve as shown in Fig 3

### Remove the safety pin from the lever valve only when ready to use.

# TUBING

Each SPA Extreme system kit is supplied with Decabon tubing which is a plastic coated aluminium tube which can be molded and flexed to suit this application. The SPA Extreme system has been designed and homologated using this type of tube. DO NOT substitute this tube for any other type.

# TUBE CONNECTIONS

All fittings for tube to nozzles and bottles are of the push-in type. Insert the tube into the fitting, push firmly until it clicks. Once in you should not be able to pull it out. To remove the tubing, push the tube into the fitting and at the same time push the black collett back towards the fitting and then pull the tube from the fitting.

## MAINTENANCE

To ensure maximum possible performance from your SPA Extreme system, the following checks and maintenance procedures should be carried out.

Regularly check Nozzles for debris or any obstructions externally or internally.

Regularly check the integrity of the pipe work and fitting.

Regularly check the cylinder for damage or corrosion.

Regularly check the mounting bracket and retaining straps are secure.

Your SPA fire suppression system must be serviced every 2 years, a service due date is written on the contents label located on your cylinder. It is up to you to ensure the services are carried out at the correct intervals.

If your system has been discharged or requires a 2 year service you must return it to SPA or an agent approved by SPA fire suppression systems.

# NOTES

Please ensure that you monitor the following **as you may not pass scrutineering if** The bottle contents label is worn, damaged or unreadable.

The system is not within service date.

The system is in poor condition.

### EXTREME DATA SHEET

Application	Autosport industry - including saloon, race cars & single seaters,
Composition	Dodecafluoro-2-methylpentan-3-one, (CF3CF2C(O)CF(CF3)2)
Ozone depletion potential	None
Operating temperature	-40 to + 80°C
Freezing point	-108°C
Critical temperature	168. <b>7°</b> C
Physicological properties	No observed adverse effect level and lowest observed adverse effect level for cardiac sensitization (halocarbon) and oxygen depletion (Inert gas).

A copy of the 3M™Novec™ 1230 fire protection fluid material safety data sheet can be obtained from SPA Design or SPA Technique upon request.